

GB Instruction for use  
LV Lietošanas pamācība

## POWERTEX Lashing Chain PLC



User Manual

# POWERTEX Lashing Chain

## Instruction for use (GB) (Original instruction)



### WARNING

- Failure to follow the regulations of this instruction for use may cause serious consequences as risk of injury.
- Read and understand these instructions before use.

### Information for use and maintenance

**1** When selecting and specifying lashing chains, consideration shall be given to the required lashing capacity, taking into account the mode of use and the nature of the load to be secured. The size, shape and weight of the load, together with the intended method of use (see EN 12195-1), transport environment and the nature of the load will affect the correct selection.

**2** The selected lashing chains shall both be strong enough and of the correct length for the mode of use. Plan the fitting and removal operations before starting a journey. Remove lifting equipment before lashing the load. Keep in mind that during longer journeys parts of the load may have to be unloaded. Calculate the number of lashing chains according to EN 12195-1.

**3** Due to different behaviour and elongation under load conditions, different lashing equipment (e.g. lashing chain, web lashings) shall not be used to lash the same load. Consideration shall also be given to ancillary components and lashing devices in the lashing, which shall be compatible with the lashing chain. Usage of equal combined lashings is admissible.

**4** Release of the lashing: It shall be ensured that the stability of the load is independent of the lashing chain and that the release of the lashing chain shall not cause the load to fall off the vehicle, thus endangering the personnel. If necessary, attach lifting equipment for further transport to the load before releasing the tensioning device in order to prevent accidental falling.

**5** Before attempting unloading the lashing chains have to be released such that the load is unhampered.

**6** During loading and lashing, unlashing and unloading attention has to be paid to low overhead power lines.

**7** Lashing chains shall be taken out of service or returned to the manufacturer for repair if they show any signs of damage.

The following are considered to be signs of damage:

- for chains: superficial fissures, elongation exceeding 3%, wear exceeding 10% of the nominal diameter, visible deformations.
- for connecting components and tensioning devices: deformations, splits, pronounced signs of wear, signs of corrosion.

**8** Care should be taken that the lashing chain is not damaged by sharp edges of the load on which it is used.

**9** Only legibly marked and labelled lashing chains shall be used.


**10** Lashing chains shall not be overloaded: Only the maximum hand force of 500 N shall be applied. Mechanical aids such as levers, bars etc. are not to be used, unless they are part of the tensioning device.

**11** Lashing chains shall never be used when knotted or connected with screws.


**12** Damage to tags shall be prevented by keeping them away from the corners of the load and, if possible, from the load.

**13** The lashing chain and the edges of the load shall be protected against abrasion and damage by using protective sleeves and/or corner protectors.

**14** Particular information on the individual type of lashing chain or lashing chain equipment and its intended use shall be given by the manufacturer.



### Back



### End of use/Disposal

Powertex lashing chains shall always be sorted/scrapped as general steel scrap.

The supplier will assist you with the disposal, if required.

### Disclaimer

We reserve the right to modify product design, materials, specifications or instructions without prior notice and without obligation to others.

If the product is modified in any way, or if it is combined with a non-compatible product/component, we take no responsibility for the consequences in regard to the safety of the product.

# POWERTEX kravas nostiprināšanas kēdes

## Lietošanas pamācība (LV)



### BRĪDINĀJUMS

- Šajā pamācībā sniegtie norādījumi neievērošana var izraisīt smagas sekas, piemēram, ievainojumu gūšanas risku.
- Pirms lietošanas izlasiet un izprotiet šos norādījumus.

### Informācija par izmantošanu un apkopi

**1** Lai izvēlētos atbilstošas kravas nostiprināšanas kēdes, ir jāņem vērā nepieciešamā nostiprināšanas slodze, nemot vērā lietošanas metodi un nostiprināmās kravas veidu. Pareizā izvēle būs atkarīga no kravas izmēra, formas un svara, kā arī paredzētās lietošanas metodes (sk. EN 12195-1), pārvadāšanas vides un kravas veida.

**2** Izvēlēto kravas nostiprināšanas kēžu stipribai un garumam ir jāatbilst to lietošanas metodei. Nostiprināšanas kēžu uzstādīšanu un noņemšanu izplānojiet pirms pārvadājuma sākšanas. Pirms kravas nostiprināšanas atvienojet celšanas aprīkojumu. Nemiet vērā, ka garāku pārvadājumu gadījumā var būt nepieciešamība izkraut atsevišķas kravas daļas. Nostiprināšanas kēžu skaitu aprēķiniet, izmantojot standartā EN 12195-1 sniegtos norādījumus.

**3** Tā kā dažāda veida kravas nostiprināšanas līdzekļi (piem., nostiprināšanas kēdes, tīkveida stiprinājumi) slodzes apstāklos reaģē un pagarinās atšķirīgi, neizmantojiet atšķirīgus kravas nostiprināšanas līdzekļus vienas un tās pašas kravas nostiprināšanai. Uzmanība jāpievērš arī palīgierīcēm un kravas nostiprināšanas ierīcēm, kurām ir jābūt savietojamām ar kravas nostiprināšanas kēdēm. Vienādu kombinētu nostiprināšanas līdzekļu izmantošana ir pieļaujama.

**4** Nostiprināšanas līdzekļu atvienošana. Jānodrošina, ka kravas stabilitāte nav atkarīga no kravas nostiprināšanas kēdes un ka nostiprināšanas kēdes atvienošana neizraisa kravas izkrišanu no transportlīdzekļa un attiecīgi apdraudējumu personālam. Ja nepieciešams, kravas tālākai pārvietošanai paredzēto celšanas iekārtu pievienojet kravai jau pirms spriegošanas ierīces atvienošanas, lai novērstu kravas nejaušu izkrišanu no transportlīdzekļa.

**5** Pirms tiek sākta izkraušana, kravas nostiprināšanas kēdes ir jāatvieno, lai tās netraucētu kravas pārvietošanu.

**6** Kravas iekraušanas un nostiprināšanas, atbrīvošanas un izkraušanas procesā ir jāpievērš uzmanība tuvumā esošiem zemu novietotiem elektrolīniju vadībām.

**7** Ja kravas nostiprināšanas kēdēm ir konstatētas jebkādas bojājuma pazīmes, tās ir jāpārtrauc izmantot vai jānodod ražotājam remonta izpildei.

Par bojājuma pazīmēm uzskata šādas pazīmes:

- kēdēm: virspusējas plāsas, izstiepšanās vairāk par 3 %, nodilums, kas pārsniedz 10 % no nominālā diametra, vizuāli konstatējamas deformācijas;
- savienojošajām detaļām un spriegošanas ierīcēm: deformācijas, plāsas, izteiktas nodiluma pazīmes, korozijas pazīmes.

**8** Jānodrošina, lai nostiprināmās kravas asās šķautnes neradītu bojājumus kravas nostiprināšanas kēdei.

**9** Atļauts izmantot tikai salasāmi markētas un ar marķējuma plāksnītēm apriņkotas kēdes.

**10** Kravas nostiprināšanas kēžu pārslagošana ir aizliepta: atļauts izmantot tikai roku spēku, kas nepārsniedz 500 N. Mehāniski palīglīdzekļi, piemēram, svīras, stienei u. tml., nav jāizmanto, izņemot gadījumus, kuros tie ir daļa no spriegošanas ierīces.


**11** Aizliegts izmantot kravas nostiprināšanas kēdes, kuras ir sasējušās mezglā vai savienotas ar skrūvēm.

**12** Marķējuma plāksnīšu bojājumi ir jānovēr, nepieļaujot to piešiešanos pie kravas šķautnēm un, ja iespējams, pie kravas.


**13** Kravas nostiprināšanas kēde un kravas šķautnes pret noberzumiem un bojājumiem ir jāaizsargā ar aizsargapvalkiem un/vai stūru aizsargiem.

**14** Ražotājam ir jāsniedz specifiska informācija par atsevišķas nostiprināšanas kēdes vai atsevišķu nostiprināšanas kēdes aprīkojuma veidu un tā paredzēto lietojumu.

### Front



### Back



### Lietošanas izbeigšana / utilizācija

Powertex kravas nostiprināšanas kēdes vienmēr ir jāšķiro / jānodod utilizācijai kā parasti tērauda metāllūžni.

Nepieciešamības gadījumā piegādātājs palīdzēs nodrošināt utilizāciju.

### Atruna

Mēs paturam tiesības modifīcēt produktu konstrukciju, materiālus, specifikācijas vai norādījums, par to iepriekš nebrīdinot un neuzņemoties pienākumus pret citām pusēm.

Ja produktu jebkādā veidā modifīcē vai kombinē ar nesavietojamu produktu/detaļu, mēs neuzņemamies neuzņemas nekādu atbildību par produkta drošību.

## CertMax+


The CertMax+ system is a unique leading edge certification management system which is ideal for managing a single asset or large equipment portfolio across multiple sites. Designed by the Lifting Solutions Group, to deliver optimum asset integrity, quality assurance and traceability, the system also improves safety and risk management levels.




## Marking

Marked according to standard: EN 12195-3

Front



Back



## User Manuals

You can always find the valid and updated User Manuals on the web.  
The manual is updated continuously and valid only in the latest version.

**NB!** The English version is the Original instruction.

The manual is available as a download under the following link:  
[www.powertex-products.com/manuals](http://www.powertex-products.com/manuals)





---

[www.powertex-products.com](http://www.powertex-products.com)